## BIOADIMIDE™ IN BIOPOLYMERS

## **EXPANDING THE PERFORMANCE OF BIO-POLYESTERS IN DURABLE APPLICATIONS**

BioAdimide™ are additive solutions specially suited to improving the hydrolysis resistance of bio-based polyester (specifically PLA) and to expanding their range of applications. The BioAdimide™ product line enables the production of renewable, bio-based polymers for durable applications with a lower environmental impact.

BioAdimide™ also allows for a greater range of process variables in terms of

- Providing melt stability during processing
- Using higher levels of re-grind material
- Enabling blending with higher melting plastics by stabilizing the bio-based polyester component

BioAdimide™ 100 is the additive of choice for superior hydrolysis stabilization of bio-based polyesters. PLA (polylactic acid) is prone to hydrolysis, but...

- Depending on the choice of BioAdimide<sup>TM</sup> service life can be increased up to 7 times compared to the unstabilized polymer (depending on test conditions).
- This extended performance makes PLA a suitable candidate for durable application markets previously out of reach.

BioAdimide™ 500 XT improves the melt stability of biobased polyesters

- Stabilized PLA does not degrade during processing and
- enables compounders to have consistent and easier processing.

Combining different BioAdimide™ grades gives added flexibility for adjusting your system according to your needs

- ... in processing (extrusion, injection molding, foams, fiber extrusion, thermoforming)
- ... of the application (automotive, electronics, appliances, construction, bath and office equipment).







#### LANXESS Deutschland GmbH **BU Additives**

Kennedyplatz 1 50569 Cologne, Germany Phone: +49 (0)221 8885-0

#### LANXESS Deutschland GmbH **BU Additives**

Duesseldorfer Str. 23-27 68219 Mannheim, Germany Phone: +49 (0)621 8907 0

#### LANXESS Limited **BU Additives**

Unit 1B, The Vo-Tec Centre Hambridge Lane Newbury, Berkshire RG14 5TN United Kingdom Phone: +44 (0)1635 568 657

#### LANXESS S.r.I. **BU Additives**

Via San Bovio 1/3 20090 Segrate, Milano, Italy Phone: +39 02 30721

#### LANXESS S.A.S **BU Additives**

11 Avenue Dubonnet 92400 Courbevoie, France Phone: +33 4 26 68 81 23

#### LANXESS Chemicals, S.L. **BU Additives**

Moll de Barcelona WTC – Edificio Norte – planta 7a 08039 Barcelona, Spain Phone + 34 93 34 15227

#### LANXESS Kimya Tic. Ltd. Sti. **BU Additives**

Fatih Sultan Mehmet Mah. Poligon Cad. Buyaka 2 Sitesi C-Blok, Kat:19 34771 Ümraniye – Istanbul, Turkey Phone +90 216 600 03 00

#### LANXESS Central Eastern Europe s.r.o **BU Additives**

Central 2 Pribinova 6 81109 Bratislava Slovak Republic Phone: +421 2 32 15 16 26

#### **OOO LANXESS Moscow BU Additives**

MIBC Moscow City, Federation Tower "B" 46th Floor, Office 1B Presnenskaya Naberezhnaya 12 123100 Moscow, Russian Federation Phone: +7 495 232 0610

#### **LANXESS Corporation BU Additives**

111 RIDC Park West Drive Pittsburgh, PA 15275-1112, USA Phone: +1 412 809 1000

#### LANXESS S.A. de C.V. **BU Additives**

Av Ejército Nacional 579 Ampliación Granada Miguel Hidalgo 11520 Mexico City, Mexico Phone: +52 55 5262 4300

#### LANXESS Indústria de Produtos Químicos e Plásticos Ltda. **BU Additives**

Av. Maria Coelho Aguiar 215 Bloco B. 2° Andar 05804-902 Jardim São Luis São Paulo-SP, Brazil Phone: + 55 11 3741 2879

#### LANXESS S.A. **BU Additives**

Luis María Drago 1555 B1852LGS Burzaco/Buenos Aires, Argentina Phone: +54 11 4002 4100 260

#### **LANXESS Hong Kong Limited BU Additives**

36/F, Cambridge House, Taikoo Place, 979 King's Road Island East, Hong Kong, PR China Phone: +852 35268885

#### Rhein Chemie (Qingdao) Ltd. **BU Additives**

43 Siliubei Road Li Cang District Qinqdao 266043, PR China Phone: +86 532 8482 9196

#### LANXESS Chemical (China) Co., Ltd. **BU Additives**

6F, 5 Corporate Avenue 150 Hu Bin Road, Huangpu District 200021 Shanghai, PR China Phone: +86 21 6109 6624

#### LANXESS Pte. Ltd. **BU Additives**

3A International Business Park #07-10/18 ICON@IBP Tower B Singapore 609935, Singapore Phone: +65 6725 5833

#### LANXESS K.K. **BU Additives**

Marunouchi Kitaguchi, Bldg. 23 F 1-6-5 Marunouchi, Chiyoda-ku Tokyo 100-8215, Japan Phone: +81 3 5293-8041

#### LANXESS Korea Ltd. **BU Rhein Chemie Additives**

9th floor, Samsung Boramae Omni Tower 23, Boramae-ro 5-qil, Dongjak-ku, Seoul, South Korea 156-712 Phone: +82 2 6715 5170

#### LANXESS India Private Limited **BU Additives**

LANXESS House Plot No. A-162-164 Road No. 27, MIDC, Wagle Estate Thane (W) - 400 604 Maharashtra, India Phone: +91 22 2587 1000

#### LANXESS Pty Ltd **BU Additives**

Suite G.08, 12 Cato Street, East Hawthorn VIC 3123, Australia Phone: +61 3 8823 8812

plastic.additives@lanxess.com add.lanxess.com

Our technical advice – whether verbal, in writing or by way of trials – is given in good faith but without warranty, and this also applies where proprietary rights of third parties are involved. It does not release you from the obligation to test the products supplied by us as to their suitability for the intended processes and uses. The application, use and processing of the products are beyond our control and, therefore, entirely your own responsibility. Should, in spite of this, liability be established for any damage, it will be limited to the value of the goods delivered by us and used by you. We will, of course, provide products of consistent quality within the scope of our General Conditions of Sale and Delivery,

BioAdimide™ is a registered trademark of LANXESS Deutschland GmbH, Germany

# **QUALITY PERFORMS.**







**BioAdimide™** in bioplastics

Expanding the performance of bio-polyester










## BIOADIMIDE™ 100

## **CREATE THE PATH TO DURABILITY**


BioAdimide<sup>™</sup> 100 gives the best hydrolytic stability and improves the service life of PLA by 3 to 7 times (depending on the dosage and testing conditions).

#### **Hydrolysis stabilization of PLA**



The improved hydrolysis performance, maintenance of polymer integrity and the slightly higher melt flow length (seen as an increased melt volume rate) makes BioAdimide™ 100 especially suitable for injection molding.

#### Melt volume rate modification of PLA



BioAdimide™ 100 leads to an endcapping of the terminal carboxylic acid groups of the polyester, which are responsible for hydrolysis, and inhibits:

- Degradation of molar mass (Mn and Mw) ...
- Degradation of the polymer ...
- ... while maintaining the desired mechanical properties of the polymer.

Molar mass stabilization of PLA					
	Mn [g/mol]	Mw [g/mol]	Polydispersity		
Unstabilized	42890	92310	2.15		
1 x extruded	39400	89200	2.26		
1.0 % BioAdimide™ 100	48570	100200	2.06		
1.5 % BioAdimide™ 100	44420	96000	2.16		

Testing conditions: Tetrahydrofuran, 40°C, viscosity detector, universal calibration.

## BIOADIMIDE™ 500 XT


## STABILIZE THE PROCESS. EXPAND THE PERFOMANCE

BioAdimide<sup>™</sup> 500 XT increases the melt viscosity (displayed by a reduced melt volume rate – MVR) of PLA after extrusion by 20 – 30 % compared to unstabilized virgin resin.

The improved melt volume rate makes it especially suitable for:

- Extrusion
- Fibers
- Blow molding

#### Melt volume rate modification of PLA



BioAdimide<sup>™</sup> 500 XT acts as a chain extender in PLA. Short and long polymer chains are re-connected without an undesirable broadening of the molar mass distribution (polydispersity) as seen with classical chain extenders.

In this way, BioAdimide™ 500 XT improves the molar mass and keeps the mechanical properties in a well-allowing defined range.


Molar mass stabilization of PLA					
	Mn [g/mol]	Mw [g/mol]	Polydispersity		
Unstabilized	42890	92310	2.15		
1 x extruded	39400	89200	2.26		
1.0 % BioAdimide™ 500 XT	59200	108000	1.82		
1.5 % BioAdimide™ 500 XT	59510	108000	1.80		

Testing conditions: tetrahydrofuran, 40°C, viscosity detector, universal calibration

In addition to the processing improvement, BioAdimide™ 500 XT improves hydrolytic stability of PLA by 2 to 3 times.

BioAdimide<sup>™</sup> 500 XT is offered as pastilles in powder, allowing for easy dosage using regular feeding equipment.

#### Hydrolysis stabilization of PLA




## COMBINING BIOADIMIDE™ 100 AND BIOADIMIDE™ 500 XT

## THE FLEXIBILITY TO EXPAND YOUR APPLICATION

Combining BioAdimide<sup>™</sup> 100 and BioAdimide<sup>™</sup> 500 XT in different ratios, the service life of PLA can be extended by 3 to 7 times. The best performer is a ratio of 2 to 1 (BioAdimide<sup>™</sup> 100 : BioAdimide<sup>™</sup> 500 XT).

### **Hydrolysis stabilization of PLA**



Using a combination of different BioAdimide™ grades:

- The molar mass remains unchanged
- Degradation is inhibited during processing Allows improved processing while leaving the molar mass distribution unchanged.

Molar mass stabilization of PLA						
	Mn [g/mol]	Mw [g/mol]	Polydispersity			
Unstabilized	42890	92310	2.15			
1 x extruded	39400	89200	2.26			
0.75% BioAdimide™ 100 + 0.75% BioAdimide™ 500 XT	48240	90100	1.86			
0.5% BioAdimide™ 100 + 1.0% BioAdimide™ 500 XT	49780	89800	1.80			
1.0% BioAdimide™ 100 + 0.5% BioAdimide™ 500 XT	45400	89040	1.96			

Testing conditions: Tetrahydrofuran, 40°C, viscosity detector, universal calibration.

The combination of BioAdimide<sup>™</sup> 100 and BioAdimide<sup>™</sup> 500 XT allows you to meet the demand for both hydrolysis stabilization and improved processing.



■ 2 BioAdimide™ in bioplastics 3 ■